A Universal Dump Program for Minicomputer Software Debugging

C. C. Klimasauskas
Communications Systems Research Section

Low-cost minicomputers in wide variety are finding application in control and monitoring tasks ranging from laboratory testing to network operation. One significant problem which arises from this circumstance is that a significantly larger minicomputer system than is needed to perform the primary tasks must be acquired to do convenient software development. Consequently, work has been underway for some time to facilitate software development for the minimal configuration minicomputer using the Medium-Scale Xerox Data Systems Sigma 5. This article describes a general-purpose memory display program which runs on the Sigma 5 to dump memory images of minicomputer software to a printer or other man-readable device. The dump is formatted, as specified by control-card options, into machine-language instructions, character strings, or virtually whatever word/byte/field format is meaningful to the current problem.

I. Introduction

Low-cost minicomputers in wide variety are finding application in control and monitoring tasks ranging from laboratory testing to network operation. One significant problem which arises from this circumstance is that a significantly larger minicomputer system than is needed to perform the primary tasks must be acquired to do convenient software development. Consequently, work has been underway for some time to facilitate software development for the minimal configuration minicomputer using the Medium-Scale Xerox Data Systems Sigma 5. A general introduction to this activity may be found in

Ref. 1. We expect ultimately to provide direct-coupled support where the minicomputer software is generated on the larger machine and is then loaded into the minicomputer and exercised via intercomputer communication links. One debugging tool which is useful, even if tedious to use, is a memory dump or display. This article describes a general-purpose memory display program which runs on the Sigma 5 to dump images of minicomputer software to a printer or other man-readable device. The dump is formatted, as specified by control-card options, into machine-language instructions, character strings, or virtually whatever word/byte/field format is meaningful to the current problem.

II. An Overview of the Processor

The universal dump program (UDP) looks at each record of the core dump (CD) as a single bit string. The user partitions this bit string into smaller units called words. Each word is partitioned further into fields (contiguous bit strings). Associated with each field is a field number and with that number a field conversion mode. Each word is indexed by an address which is specified dynamically by telling the UDP where to find the first address of the word or statically through specification. The address may be incremented by one or the number of bytes per word as specified through the addressing mode. The user has the option of indicating the conversion mode for the address, and the word, in addition to each field.

The first step in this process is description of the target machine. This phase generates tables which describe word size, byte size, field characteristics, conversion modes and all other data required to generate the dump. This phase produces syntax error messages and warnings. The following sections give a detailed description of the syntax of target machine description and listing format specification.


The next phase analyzes the tables for consistency and interpolates where possible to produce a complete set of consistent tables to drive the actual dump generator. This phase may find fatal specification errors which will prevent further execution. It also produces warning messages for nonfatal errors. A following section contains a complete description of all error messages.

Phase three is the actual routine for producing the dump listing. This program acts as a set of table-driven subroutines under the control of a single control routine. Figure 1 describes these program steps diagramatically. The program is implemented in Xerox Data Systems META-SYMBOL on the Sigma 5 computer to be run under the Batch Processing Monitor. On the right-hand side of Fig. 1 is the overlay structure of the program. Each of the files to produce this resides on magnetic tape in the standard Xerox Data Systems 7-track labeled-tape format. The source file for each overlay is followed by its corresponding binary file (in parentheses).

III. Conventions for Syntax Definition

This section presents some general comments which describe the meaning of the constructions used in defining syntax.

- (1) The bracket construction:
 - [] indicates that those items contained within the brackets are optional
 - [...] indicates indefinite continuation of the optional construction in which this is imbedded.
- (2) The brace construction:



(3) Upper case literals and symbols:

These are key words and delimiters which *must* occur exactly as shown.

(4) Lower case phrases and letters:

These are representative of other constructions which must be supplied according to elsewhere defined syntax. For instance, the phrase "usge" occurs many times in the description of the syntax. This phrase represents a numeric constant and has the syntax described at the beginning of Section IV.

(5) Blanks or spaces:

Unless specifically noted, blanks are *not* allowed between characters. Three exceptions:

- (a) _ signifies that exactly one blank is mandatory.
- (b) signifies that one or more blanks are optional.
- (c) The blank occurs as part of a string as defined for the syntax of the particular statement. For example, see "constant literal field" under PRTDEF in Section IV.

IV. The Syntax of Machine Description and Listing Format Specification

Before describing the syntax, some general comments about constants, control cards, and comment cards are presented.

There are two classes of constants: (1) explicit or specified and (2) implicit. The explicit or specified constant will be denoted by "ussc" and the implicit constant by "usgc." The syntax of each of these is given below:

as specified by the syntax of the statement.

Control cards must always have an asterisk in column one. Blanks are not allowed in control cards except where specifically noted. If the definition of a control card requires more than one physical card, continuation cards must not have an asterisk in column one. All other cards will be printed exactly as punched and may be used for documentation purposes.

As we consider in detail the syntax of each statement, we will first define its purpose and make general comments, then give the actual syntax and describe the various options which are possible. As we proceed, it may be helpful to study the decks and resulting dumps shown in Figs. 2 and 3.

A. WORD Specification (Target Machine Description)

This statement simply describes the length in bits of each word of the target machine. Since these are partitions of a continuous bit string, they are referred to as p-words or "partion words." (When each p-word is printed, first the address of the word is printed, then the contents, then the alphanumeric representation of the contents, and finally the user-defined fields). The syntax is as follows:

where usgc is the number of bits per target machine word.

B. BYTE Specification (Target Machine Description)

This card is optional and is used for the purpose of computing the target machine address of the current p-word. This card must be used if byte addressing is specified. (See ADDRESS specification.) The syntax is as follows:

where usgc is the number of bits per target machine byte.

C. ADDRESS Specification (Target Machine Descriptor and Listing Format Specification)

This card defines the addressing mode of the target machine for the purpose of generating a pseudoaddress for the current p-word on the dump listing. Two modes are available: Byte and Word (default) addressing. Byte addressing increments the listing location counter by the number of bytes per word for each successive instruction. The conversion mode for the address can be optionally specified. The syntax is as follows:

*ADDRESS =
$$\left\{ \begin{array}{c} \text{BYTE} \\ \text{WORD} \end{array} \right\} \left[\begin{array}{c} \text{HEX} \\ \text{DEC} \\ \text{OCT} \end{array} \right]$$

D. CHAR and SPECIAL Specifications (Target Machine Descriptors)

The CHAR card defines the actual width of a character and the number of right-justified significant bits needed to decode the character. For instance, ASCII characters are eight bits wide; however, the right seven bits actually contain all the character information. Three widely used character codes have been incorporated into the program. Provision is made for user-defined character conversion codes. The syntax of the CHAR specification is as follows:

$$*CHAR = \left(\begin{array}{c} ANSCII \\ ASCII \\ EBCDIC \\ BCD \\ SPCL \end{array}\right) [(usgc_1, usgc_2)]$$

where

 $usgc_1 = the width of a character in bits.$

 $usgc_2 = the number of right-justified significant bits per character.$

If SPCL is specified, the actual binary-to-character conversion table must be specified. This is done through the SPECIAL card. The syntax is as follows:

*SPECIAL=usge
$$\sqcup$$
 character string₁
 \sqcup character string₂
 \vdots
 \vdots
 \sqcup character string₄

where

usgc ≡ the number of characters per character string. Because of the physical limitations of a card, this is at most

□ = a required space. The first column must be blank.

character string $_i \equiv$ the *i*th contiguous string of characters in the binary-to-alphanumeric conversion vector. The ith character1 in the character conversion vector should be (a) a period, if no valid extended alphanumeric character corresponds to the target machine's internal binary representation of ior if the character is not printable, or (b) the actual character if the target machine's internal binary representation of *i* corresponds to that character. (For example: in EBCDIC, for j = 253, the internal binary representation of i is 1111 1101 and does not correspond to a valid character, so the 253rd character in the conversion vector is a period. For j = 240, the internal binary representation of j is 1111 0000. This corresponds to the character "Ø"; hence, the 240th character in the conversion vector is \emptyset .)

E. ROTATE Specification (Target Machine Preprocessing Descriptor)

In certain modes of operation, the halfwords may be swapped due to the method of transmission. This occurs, for instance, in the I/O processes of the PDP-11. It may also be desirable to rotate the contents of each word before breaking it into fields and decoding it. The ROTATE specification causes each p-word to be rotated right the number of bits specified. This occurs before any other procession on a record is done. The syntax is as follows:

*ROTATE:usgc

where

usgc is the number of bits to right-rotate each p-word before processing.

F. INSDEF Specification Card (Listing Format Specification)

INSDEF partitions the word into contiguous fields of bits. Each field has a corresponding field number which associates it with a print field (see PRTDEF). The syntax is as follows:

*INSDEF: $f_1 f_2 f_3 \dots f_r$

where

 f_i is the *i*th contiguous string of bits corresponding to a print field; f_i itself is a contiguous string of digits (all the same) in the form dddd...d, where d takes on values 0–9. When d=0, the field is ignored. When $d\neq 0$, the field corresponds to the *d*th print field and will be connected for printing according to the attributes of the *d*th print field. If $\ell(f_i)$ represents the number of bits in field

$$i, \sum_{i=1}^{r} \ell(f_i)$$

must equal the number of bits per p-word. Hence $f_1f_2\dots f_r$ partitions the p-word into bit fields. \blacktriangle is an optional string of blanks.

G. PRTDEF Specification Card (Listing Format Specification)

PRTDEF specifies the type of conversion to perform when printing the bit fields of a p-word. It allows for inclusion of unchanging literals, conversion mode specifies, and zero width field delimiters. The syntax is as follows:

*PRTDEF: $f_1 f_2 \dots f_r$

where

f_i is a field of one of three types:

- (1) An unchanging literal field. This field is always printed exactly as it appears on the PRTDEF card, with the exceptions noted under the SKIP and NULL attributes described later. This field may not contain any of the following characters: M,X,O,D,B,C,L,:.
- (2) A conversion mode field. The jth conversion mode field is the dth print field (j=d) described under INSDEF. This field describes the mode of conversion (X-hexadecimal, O-octal, D-decimal, B-binary, C-character, M-mnemonic, L-literal) and the number of print positions allocated to printing the field. (Note: the rightmost characters of the field are always printed. Truncation always occurs to the left.) The general format of the field is $S_1S_2...S_n$ where $S_1=S_2=...=S_n=S$, and $S_n=1$

¹The index j starts at zero and goes through 2** (number of significant bits/character) -1 in steps of one.

defines the conversion mode as above; n is the width of the field in characters. For all but literal and mnemonic conversion, the maximum width is 12. For literals and mnemonics, the maximum is 4. There may be only *one* mnemonic field.

(3) A zero-width field delimiter. This is simply the character ':'. It serves to delimit two fields with the same conversion mode.

H. HEAD Specification Card (Listing Format Specification)

This card allows the user to put a heading at the top of each column of each page of listing. The header appears above the user-defined print fields. The first character after the colon appears immediately above the first character following the colon on the PRTDEF card (see PRTDEF). The syntax is as follows:

*HEAD: literal string

where 'literal string' is the user-defined header.

I. PARAM Specification Card (Listing Format Specification)

The PARAM card allows the user to modify the conversion mode of a print field when it is undesirable to print it. This card also is used to enter the literal table if the literal conversion mode was specified on the PRTDEF card. The syntax is as follows:

*PARAM: usgc₁
$$= \left(\left\{ \begin{array}{c} SKIP \\ NULL \end{array} \right\} \left[\begin{array}{c} \left\{ \begin{array}{c} SKIP \\ \\ NULL \end{array} \right] \left[\left\{ \begin{array}{c} > \\ < \\ = \\ \neg \end{array} \right] \left[\left\{ \begin{array}{c} > \\ < \\ = \\ \neg \end{array} \right] \right] usgc_2 \right] \right) \right]$$

[,LIT = lit_0 , lit_1 , lit_3 , ..., lit_n]

where:

usgc₁ is the print field to be modified.

SKIP indicates that, following the current conversion mode field, blanks should be inserted to the end of the line and no further conversions made. This will occur if the SKIP-NULL condition is satisfied (see below); i.e., if the SKIP-NULL condition is satisfied, skip to the end of the line.

NULL indicates that the current conversion mode field and the preceding unchanging literal field should be blanked out. This will occur if the SKIP-NULL condition is satisfied.

SKIP-NULL condition: The relation operators in conjunction with usgc₂ form the SKIP-NULL condition. There may be a linear combination of at most two relational operators. If the relation thus defined between the contents of the current field and usgc₂ holds, the SKIP-NULL condition is '=0'. For the mnemonic conversion mode, the SKIP-NULL condition is implicitly satisfied if the operation code has not been assigned a mnemonic. In this case, an implicit NULL is performed, regardless of specification.

 $\operatorname{lit}_0, \operatorname{lit}_1, \ldots, \operatorname{lit}_n$ is the literal conversion vector for the current field if the literal conversion mode is specified. There are $n=2^r-1$ literals in this vector, where r is the bit width of the print field. Commas are used to delimit the literals. The *i*th literal corresponds to the internal binary representation of i (i takes on values 0 through 2^r-1).

J. OPS Specification (Listing Format Specification)

This card makes a one-to-one correspondence between machine operation codes and mnemonics. It builds the table for the mnemonic conversion field specified on the PRTDEF card. The syntax is as follows:

$$*OPS = \left\{ \begin{array}{c} HEX \\ DEC \\ OCT \end{array} \right\}$$

 $ussc_1$, literal $string_1$ $ussc_2$, literal $string_2$

. ussc_r, literal string_r ussc_n, literal string_n

where

ussc_i is the opcode for some instruction. ussc_i is decoded as if it were in the mode specified by the 'OPS='card.

literal string $_{i}$ is the mnemonic corresponding to opcode ussc $_{i}$.

This card must follow the PRTDEF card.

K. BIN Specification (Listing Format Specification)

This card defines the mode of conversion for printing the contents of the entire p-word. (When each p-word is printed, first the address of the word, then its contents, in the mode specified by the BIN card, then the alphanumeric equivalent of the contents, and finally the userdefined fields are printed.) The syntax is as follows:

$$*BIN = \left\{ \begin{matrix} HEX \\ DEC \\ OCT \end{matrix} \right\}$$

L. START and NEWLOC Specification (Listing Format Specification)

The purpose of START is to establish the initial value of the location counter for the address of the first p-word of the first record. If no NEWLOC card is present, the location counter is incremented for following records as if they were contiguous with the first. (This assumes that the core dump consists of more than one physical record.) This value may be explicitly stated or the program may be told where to find it in the first record. The syntax to do this is as follows:

$$*START = \begin{cases} usgc_1 \\ REC[+usgc_2]:f_1f_2f_3[\{\pm\}usgc_3] \end{cases}$$

where

usgc₁ is the initial value of the location counter for listing purposes. REC indicates that the initial location will be found within the record. usgc₂ indicates the offset of the word in the record which contains the initial value of the location counter. (The word accessed is $usgc_2+1$.) $f_1f_2f_3$ forms a mask for extracting the location from the word. f_1 and f_3 are strings of zeros indicating bits to ignore. Either may be null. f_2 is the mask for extracting the bits which represent the initial location. It consists of a string of Ns. The total length of the three strings must be the number of bits per

p-word. $usgc_3$ is an offset to be added to the address extracted, before using it as the initial value of the listing location counter.

NEWLOC performs exactly the same function as START and has the same syntax. However, NEWLOC applies to the second and each succeeding record. If the record mode is specified, it is assumed that each record is treated exactly the same as if it were the first record and START where specified with these parameters. If an absolute starting location is given under NEWLOC, this applies to the second record only, and each succeeding record is treated as if it were contiguous to the preceding record and the location counter is incremented appropriately. The syntax of NEWLOC is as follows:

$$*NEWLOC = \begin{cases} usgc_1 \\ REC[+usgc_2]:f_1f_2f_3[\{\pm\}usgc_3] \end{cases}$$

where each symbol has the same meaning as for START.

Table 1 gives an incidence matrix which shows those cards that are necessary and any cards which they must precede. Those items in the left column must either precede, follow, or are optional with respect to the items across the top. This table should be helpful to the user for setting up a deck. If a card is optional, except in the presence of another, this is also noted. For instance, BYTE must precede the ADDRESS specification if used.

M. END Specification

The END card delimits the description deck and calls in the consistency analyzer. This must be the last card in the description deck. The syntax is as follows:

*END

This concludes the discussion of the syntax of target machine description and listing format specification. Actual examples of each of the statements are shown in Figs. 2 and 3.

V. Program Limitations and Diagnostics

The Universal Dump Program is aimed at minicomputers, and this is reflected in some design limitations. Even so, it is very flexible, and should provide no insurmountable limitations to the user. Table 2 describes its characteristics and limitations.

The initial phases of the program produce a considerable quantity of diagnostics designed specifically to aid the user in quickly identifying and correcting controldeck errors. Because of this, and the philosophy that a program should be executed if at all possible, most diagnostics do not prevent continued execution of the program. In the initial syntax analysis section, diagnostics do not prevent continued execution, although a FAILURE will terminate processing of that statement. All consistency checks will be made on the tables, even though fatal errors in consistency may be discovered. Fatal errors prevent execution of the listing phase and termination will occur. Nonfatal errors (WARNINGS) have no effect on continued execution and are merely to call the user's attention to unusual conditions. Table 3 lists possible errors, their probable cause, and fatality.

VI. Two Examples of Use

In this section we consider two examples to illustrate use of the program. The first decodes a dump of part of the monitor program for the XDS 930 computer, which is a second-generation machine that uses word addressing. The word is 24 bits, character code BCD, and usual listing mode OCTAL. The first record is a bootstrap which loads into location 2. Each following record is in absolute loadable binary form, with load location infor-

mation in the second word. The instruction format is shown in Fig. 4. For a further description of the 930, see the *XDS* 930 *Computer Reference Manual*. Figure 2 illustrates how this information was used to generate a machine description deck. Figure 2 also shows the resulting dump.

The second example is from a considerably different machine, the PDP-11, manufactured by Digital Equipment Corporation. The PDP-11 is a medium-speed, thirdgeneration minicomputer. It has 16-bit words, which are byte-addressable, and uses the ASCII character set. The usual listing mode is octal. The example here is a dump of an I/O routine in the standard PDP-11 absolute dump format. This format swaps the low- and high-order bytes in each word, making it necessary to reverse them before analyzing a record. This was done by means of the ROTATE command. Address information is contained in the third word of each record. The PDP-11 uses the first four bits of each word as an op-code, and for the op-codes '00' and '10', other bits in the word are used as modifiers. This condition is indicated by using the mnemonics SPCL and SPLB, respectively. The PDP-11 instruction format is shown in Fig. 5. For a further description of the PDP-11 instructions, see the PDP-11/20 Processor Handbook (Digital Equipment Corp.). Figure 3 shows the actual specification deck and dump listing for the I/O routine.

Reference

 Layland, J. W., "An Introduction to Minicomputer Software Support," Klimasauskas, C. C., "The X930 Program Set for Sigma 5 Assembly," Erickson, D. E., The SAPDP Program Set for Sigma 5 Assembly," The Deep Space Network Progress Report, Technical Report 32-1526, Vol. VII, pp. 84-96, Jet Propulsion Laboratory, Pasadena, Calif., Feb. 15, 1972.

Table 1. The order of heirarchy of specification cards

O-may optionally precede or follow

P-must precede the statement on the top of the matrix

F-must follow the statement on the top of the matrix

blank-optional card

	WORD	BYTE	ADDRESS	CHAR	SPECIAL	ROTATE	INSDEF	PRTDEF	HEAD	PARAM	OPS	BIN	START	NEWLOC
WORD	-	P	P	P	P	P	P	P	O	P	P	O	P	P
BYTE		-	Pa											
ADDRESS														
CHAR	О	О	O	_	O	O	O	О	O	O	O	O	O	O
SPECIAL				\mathbf{F}^{b}	-									
ROTATE														
INSDEF	F	О	O	О	О	О	-	О	O	P	P	O	O	О
PRTDEF	F	О	О	O	О	О	О	_	О	P	P	O	О	О
HEAD														
PARAM	F	O	О	О	O	O	F	F	О		O	O	О	O
OPS	F	О	O	О	О	О	\mathbf{F}	F	О	О	-	О	О	О
BIN												_		
START	F	О	О	О	O	О	О	О	О	О	O	О	-	О
NEWLOC	F													

 $^{^{\}rm a}{\rm BYTE}$ must be specified before address if byte addressing mode is used.

Table 2. Characteristics and limitations on the Universal Dump Program

Characteristic	Minimum	Maximum
p-word length (bits)	2	32
Binary, octal, decimal, hexadecimal, character field width (print positions)	1	12
Literal and mnemonic field width (print positions)	1	4
Location counter characters (print positions)	5	5
Buffer size (bits) (current implementation)	$2 imes 10^5$	$5 imes 10^{5}$

^bSPECIAL must be used if and only if SPCL is specified for character type.

Table 3. Error messages

Syntax errors (syntax analysis phase: nonfatal)					
Message	Meaning	Message	Meaning		
FAILURE: UNEXPECTED END OF LINE ENCOUNTERED	Syntax scan expected to see a character, but came to end of card first	FAILURE: MUST HAVE WORD LENGTH BEFORE INSDEF—YOU LOSE	WORD card must precede INSDEF statement		
WARNING: CARD WAS NOT COMPLETELY PROCESSED	Syntax scan ended and released card, yet nonblank characters still remain	WARNING: DEFINED INS LENGTH AND ACTUAL INS LENGTH DIFFER	Self-explanatory in context of INSDEF statement		
WARNING: I/O ERROR- ABORT**	An irrecoverable I/O error has occurred and program has aborted (fatal)	WARNING: ILLEGAL FIELD DEF CHARACTER SCAN ENDED	Self-explanatory		
WARNING: END CARD SUPPLIED—NO EXTRA CHARGE	End-of-file on card input was encountered before an *END card	FAILURE: ONLY ONE PRTDEF CARD ALLOWED —THIS IGNORED	One or more PRTDEF cards have been processed		
FAILURE: ILLEGAL SIZE: MUST BE (1-32) FAILURE: CANNOT REDEFINE WORD SIZE—	Self-explanatory Attempt to redefine size of a p-word—ignored	FAILURE: UNKNOWN CHAR TYPE: ANSCII, ASCII, BCD, EBCDIC, SPCL, EXPECTED	Self-explanatory in context of CHAR card		
ERROR FAILURE: ILLEGAL BYTE LENGTH	Length of byte is zero, greater than the length of a p-word,	FAILURE: CANNOT REASSIGN CHARACTER TYPE	One or more CHAR cards have been processed		
FAILURE: CANNOT REDEFINE BYTE LENGTH	or p-word length has not been defined Attempt to redefine byte length has been made	FAILURE: CHARACTERS ARE LONGER THAN ONE WORD	Self-explanatory		
WARNING: WORD IS NOT BYTE MULTIPLE	The p-word is not an even byte multiple	FAILURE: WORD IS NOT AN EVEN CHARACTER MULTIPLE	Self-explanatory		
FAILURE: BYTE LENGTH: UNDEFINED— IGNORED	The byte length must be defined before the ADDRESS card is used	FAILURE: ILLEGAL CHARACTER, COMMA EXPECTED	Self-explanatory		
FAILURE: ILLEGAL PARAMS: WORD OR BYTE EXPECTED	Self-explanatory diagnostic of ADDRESS card	FAILURE: MASK IS LARGER THAN	Self-explanatory		
FAILURE: ROTATE OPTION ALREADY IN EFFECT	Self-explanatory	CHARACTER FAILURE: ILLEGAL	Self-explanatory		
FAILURE: ROTATE BITS > = WORD LENGTH; OR WORD LENGTH = 0	Self-explanatory	CHAR, RT PAREN EXPECTED	0707		
FAILURE: ATTEMPT TO REDEFINE START/	Self-explanatory .	FAILURE: NO SPECIAL CHARACTER TABLE NEEDED	SPCL was not an option on the CHAR card		
NEWLOC FAILURE: ILLEGAL FIELD FMT (:)	Self-explanatory	FAILURE: MAX OF 79 CHAR/CARD EXCEEDED	Self-explanatory		
EXPECTED WARNING: MASK AND WORD ARE UNEQUAL	Self-explanatory in context of START/NEWLOC card	FAILURE: NO CHAR NEEDED—WIDTH IS ZERO	SPCL card has occurred before CHAR card		
MASK ASSUMED RT JUSTIFIED FAILURE: ATTEMPT TO REDEFINE INSTRUCTION	One or more INFDEF cards have already been processed	FAILURE: UNEXPECTED END OF CARD	A control card was encoun- tered before the character conversion vector was completed		

Table 3 (contd)

	Syntax errors (syntax ar	nalysis phase: nonfatal)			
Message	Meaning	Message	Meaning		
FAILURE: ILLEGAL TYPE: HEX,DEC,OCT EXPECTED	Self-explanatory in context of BIN card	FAILURE: NO MNEMONIC FIELD FOR INSTRUCTION.	PRTDEF card did not have a mnemonic field or has not been encountered yet		
FAILURE: UNIDENTIFIED PARAMETER JUST ENCOUNTERED	SKIP/NULL expected while scanning PARAM card—not found	WARNING: OP OUT OF RANGE—IGNORED	An op-code greater than maximum found while processing OPS card		
WARNING: MISSING PRNTDEF FIELD— WIDTH OF 4 ASSUMED	PARAM card precedes the PRTDEF card	FAILURE: DYNAMIC STORAGE ALL ALLO-	Insufficient core available to complete processing of		
WARNING: INCORRECT NUMBER OF LITERALS	The number of literals on the PARAM card is less than needed to complete the	CATED—NONE LEFT	description deck		
	binary-to-literal conversion vector	WARNING: THIS IS THE END	Normal message indicating completion of syntax phase		
	Syntax errors (table analys	is phase: FAILURES are fatal)			
Message	Meaning	Message	Meaning		
WARNING: ZERO BYTES/ WRD—ONE ASSUMED	Self-explanatory	FAILURE: ZERO FIELD WIDTH—FIELD:XX	PRTDEF field, but no cor- responding field on INSDEF card (i.e., too many PRTDEF fields)		
FAILURE: ZERO WIDTH CHARACTERS	An irrecoverable error occurred while processing the				
FAILURE: IMPROPER CHARACTER FIELD WIDTH	CHAR card, or field width specifications are in error	FAILURE: NO CONVERSION TYPE—FIELD:XX	Too many INSDEF fields and no corresponding PRTDEF field		
WARNING: NO CHR OPT —EBCDIC ASSUMED	No CHAR card in description deck	WARNING: LIT ENTRY,	LIT option specified on		
FAILURE: SPECIAL CHARACTER TABLE IS NULL	SPCL was specified on the CHAR card, but no SPECIAL card was validly processed	BUT CNVRSN TYPE NOT LIT—FIELD:XX	PARAM card, but conversion type from PRTDEF was not literal mode		
WARNING: TOTAL PRINT FIELD > 33 CHR— TRUNCATED	The number of characters required to print the location, contents, and user fields exceeds 33 characters	FAILURE: PARAMETER ENTRY AFTER END OF FIELD IN PSN:XX	Field specified on a PARAM card is greater than any PRTDEF field		
FAILURE: NO PRTDEF CARD PRESENT	Self-explanatory	WARNING: EXTRACT MSK, BUT NULL FIELD—	INSDEF field is not related to any PRTDEF field		
FAILURE: NO INSDEF CARD PRESENT	Self-explanatory	FIELD:XX WARNING: LITS, BUT	PARAM card for undefined		
FAILURE: LIT/MNE, BUT NO LIT ENTRY—FIELD:	L or M specification on PRTDEF, but no 'LIT' on	NULL FIELD—FIELD:XX	PRTDEF field has LIT option		
XX	PARAM card or OPS card respectively	WARNING: PARAMS, BUT NULL FIELD: FIELD:XX	PARAM card for undefined field		
XX is the field number (1–9).					




Fig. 1. Dump Program diagram

```
12:14 MAY 29, 73 ID=1011=F00
    ASSIGN M:SI, (DEVICE, CRADS), (IN)
ASSIGN M:EI, (DEVICE, 77), (IN), (SN, TST)
    RUN (LMN.DUMP)
  *WARD = 24
 *BYTE=6
*ADDRESS*WORD.GCT
 *CHAR=BCD
*BIN=ACT
 *PARAM:1 = ( CKIP)
  *PARAM: P=(NULL), LIT=,
  *PARAM:4=(NULL)aliT=aPP.XaPX
  *HEAD:MNU* ADD TO
 *OPS*BCT
 WARNING: THIS IS THE END
 ***CONSISTENCY TEST FOR TABLES***
   LOC LILLILLE AAAA MNU* ADD TG LOC LILLILL AAAA MNU* ADD TG LOC LILLILL AAAA MNU* ADD TG LOC LILLILL AAAA MNU* ADD TG
00104 07600231 7 21 LDA 00231
00105 07300230 7H2H SKG 00230
00106 03700231 3Y21 STX 00231
00107 04630003 4T03 RCH 30003
00110 07500260 7Q2 LDB 00260
00111 06700003 6Y03 LSH 00003
                                                                                                                                                                                                                                                       00150 01740256 1(2; E8R+00256
                                                                                                                                                                                                                                                       00151 03500254 302* STA 00254
00152 07640256 7U2; LDA*00256
00153 05300255 5H2* SKN 00255
                                                                                                                                     WIM 00660.x
                                                                                                                                                                                                                                                       00154 05500243 5Q2L ADD 00243
00155 03540257 3+2+ STA+00257
00002 23200012 C+0 WIM 00012/X
00003 04100002 4802 58X 00002
00004 07100011 7809 LDX 00011
00005 23200000 C+00 WIM 00000/X
00006 0402100C 4280 58X 00005
00010 00100012 080 84W 00012
00011 00040012 040 HLT+00012
00012 07500236 702< LDB 00236
00013 07600237 7 2+ LDA 00237
0014 05400240 5-2- SLB 00240
0015 0350241 362U STA 00241
00016 03540241 362U STA 00241
00017 07040241 742U SKM*00241
00020 00150014 5808 B4U 00014
                                                                                   00046 00100045 080N BRU 00045 00047 04020010 4208 SKS 20010
                                                                                                                                                                     00112 03500246 3028 STA 00246
00113 07600247 7 2P LDA 00247
                                                                                                                                                                                                                                                       00156 06100256 682, MIN 00256
00157 06100257 682. MIN 00257
                                                                                   00050 00100210 0828 BRU 00210 00051 07600260 7 2 LDA 00260
                                                                                                                                                                     00114 06700006 6Y06 LSH 00006
00115 05400250 5+20 SUB 00250
                                                                                                                                                                                                                                                       00160 07600255 7 2. LDA 00255
00161 06700001 6Y01 LSH 00001
                                                                                   00052 07500252 702. LDB 00252 00053 07000227 7020 SKM 00227
                                                                                                                                                                     00116 03500251 302R STA 00251
00117 07600260 7 2 LDA 00260
                                                                                                                                                                                                                                                       00162 03500255 302. STA 00255
00163 06000251 602R SKR 00251
                                                                                                                                                                                                                                 00260
                                                                                   00054 00100107 0817 BRU 00107
00055 01400253 1=2# ETR 00253
00056 03500231 3021 STA 00231
00057 07600222 7 28 LDA 00222
                                                                                                                                                                     00120 01400252 1-2. ETR 00252
00121 01700253 172$ EGR 00253
00122 01700261 172/ EGR 00261
00123 03500254 302* STA 00254
                                                                                                                                                                                                                                                       00164 02000207 2027 NBP 00207
00165 05300251 5H2R SKN 00251
                                                                                                                                                                                                                                                       00166 00100147 081P BRU 00147
00167 07600261 7 2/ LDA 00261
                                                                                                                                                                    00123 03500284 302* STA 00254
00124 07100251 782R LOX 00251
00125 27600263 G 27 LDA 00263,X
00126 01700236 1Y2< EDR 00236
00127 03500255 302* STA 00255
00130 07600261 7 2/ LDA 00261
00131 07200225 7+2E SKA 00225
00132 00100136 081< BRU 00136
00133 06100251 682R MIN 00251
00134 07500236 702< LDB 00236
00135 03600255 3 2* STR 00255
                                                                                                                                                                                                                                                       00170 07200225 7+2E SKA 00225
00171 00100174 081( BRU 00174
00172 07600254 7 2+ LDA 00254
00173 00100177 081 BRU 00177
00174 07600254 7 2+ LDA 00254
00175 01740256 142; E8R+00256
                                                                                    00060 03500230 362H STA 00230
                                                                                   00061 07100230 782H LDX 00230
00062 27600260 G 2 LDA 00260,x
 00020 00100014 0808 BRU 00014
00021 05400242 5-2K SUB 00242
                                                                                   00064 01400232 1-2 ETR 00232
00065 03500233 302. STA 00233
                                                                                   00066 03500243 302. STA 00233
00066 05500230 5024 ADD 00230
00067 03500230 3024 STA 00230
00070 05500234 5023 ADD 00234
00071 05500121 3011 STA 00101
0072 07600233 7 2. LDA 00233
 00022 00100030 080H BRU 00030
                                                                                                                                                                                                                                                       00176 03500254 3Q2+ STA 00254
00177 06600014 6 08 RSH 00014
00023 00000000 0000 HLT 00000
00024 0000001 0001 WLT 00001
                                                                                                                                                                                                                                                       00200 01700254 1Y2* EDR 00254
00201 07500253 702* LDB 00253
00202 07000260 702 SKM 00260
00025 40000000 1001 41 00001
00026 40000000 -000 HLT 00000
00026 77777777 ... EAX*37777,F
00027 00037777 03. HLT 37777
00030 03500243 302L STA 00243
00031 07600231 7 21 LDA 00231
00032 07200236 7424 STA 00236
                                                                                                                                                                     00134 07500236 7G2< LDB 00236 00135 03600255 3 2. STB 00255 00136 05500243 5Q2L AND 00243 00137 03500257 3Q2< STA 00257 00140 07600246 7 2B LDA 00246 00141 07500164 7Q1U LDB 00164 00142 07200253 7+2$ SKA 00253
                                                                                                                                                                                                                                                       00202 07000260 702 SKM 00260
00203 00000004 0004 HLT 00004
                                                                                   00073 05500235 502. ADD 00235
                                                                                                                                                                                                                                                       00204 02000004 2004 NBP 00004
00205 07600224 7 20 LDA 00224
                                                                                    00075 04630003 4T03 RCH 30003
                                                                                                                                                                                                                                                       00206 07500025 7Q0E LDB 00225
00207 00100031 0801 BRU 00031
00210 04010410 4148 SKS 10410
00211 04021000 4280 SKS 21000
00212 00100210 0828 BRU 00210
00213 00207630 0++H EBM 07630
                                                                                   00077 03500233 302. STA 00233
00100 07100233 782. LDX 00233
00101 27600260 g 2 LDA 00260
00102 23500260 Cd2 STA 00260
                                                                                                                                                                     00142 07200233 7425 SKA 00233
00143 03600257 3 2. STB 00257
00144 07100247 782P LDX 00247
 00033 00100061 0897 BRU 00061
00034 03500244 362M STA 00244
00035 04010410 4148 SKS 10410
00036 04071000 4280 SKS 21000
00037 00100035 080 880 00035
                                                                                                                                                                     00145 07700262 7Y28 EAX 00262
00146 03700256 3Y2; STX 00256
                                                                                                                                              00260.X
                                                                                    00103 04100101 4811 BRX 00101
                                                                                                                                                                      00147 07600254 7 2+ LDA
```

Fig. 2. An application of the Universal Dump Program to the XDS 930 computer

```
LOC IILILILL AAAA MAU* ADD TG
                                                                 LOC LILLLEL AAAA MNU* ADD TG LOC LILLLEL AAAA MNU* ADD TG
                                                                                                                                                                                                      LOC LULLUL AAAA MNU* ADD TG
00214 04021000 4220 SKS 21000 '
                                                                                                                                                                                                       05315 64606060 H
                                                                                                                                                                                                                                               RCH 06060*X
                                                                                                                                     05301 04377767 4 . . x 88M#37767
00215 0010021+ 0825 583 21300
00216 0610024+ 6824 MIN 00244
00217 07600244 7 28 LDA 00244
                                                                  05302 00210325 0A3E E8M 10325
05303 07610325 7/3E LDA 10325
                                                                                                                                                                                                       05316 40007776 =0.. HLT 07776
05317 50627062 psys
                                                                                                                                     05304 07211170 7494
                                                                                                                                                                                                       05320 31606060 I MRG 06060.
05321 40007765 -0.V HLT 07765
                                                                                                                                                                                                                                             MRG 06060.PX
00220 07300245 7H2K SK3 00245
                                                                                                                                     05305 00107675 08 .. BRU 07675
00221 00100035 080+ 399 00035
                                                                                                                                                                                                        05322 50627062 OSYS
                                                                                                                                     05306 00100365 083V BRU 00365
05307 04107606 48.6 BRX 07606
00222 00000001 0001 4LT 00001
00223 02000001 2001 4LT 00001
00224 0000260 0020 HLT 00200
                                                                  05243 03350561 3.5/ PIN*10561
                                                                                                                                                                                                        05323 60606060
                                                                  05244 02105245 28.A
05245 50627062 08YS
                                                                                                                                     05310 00107660 08. BRU 07660
05311 03510330 3R3H STA 10330
                                                                                                                                                                                                        05324 40007767 -0.X HLT 07767
05325 11111111 9999
                                                                                                                                                                                                        05326 00000000 0000 HLT 00000
05327 04377767 4..X BRM*37767
00225 02000000 2000 NAP 00000
00226 77777400 **(0 EAX*37400)
                                                                  05246 63476060 TP
05247 40007235 -0.. HLT 07235
                                                                                                                                     05312 01411171 1J97 FTR 11171
                                                                  00227 00030000 0300 HLT 00000
00230 00000000 0000 HLT 00000
00231 00000000 0000 HLT 00000
00232 00000077 000 HLT 00077
                                                                                                                                                                                                       05330 00410325 0J3E
05331 04377767 4..x BRM#37767
                                                                                                                                                                                                      05332 00210325 0A3E E0M 10325
05333 07610325 7/3E LDA 10325
00233 00000000 0000 HLT 00060
00234 27600260 G 2 LDA 00260 X
00235 23500260 CG2 STA 00260 X
00236 77777777 .... EAX*377777
                                                                                                                                                                                                       05334 07211170 7A9Y SKA 11170
                                                                                                                                                                                                        05335 00107675
                                                                                                                                                                                                                                     08 . BRU 07675
00235 23500260 CG? STA 00260;X
00236 777777777777 **** EAX*37777;P
00237 70043700 G**0 HLT 03700
00240 00004600 0000 HLT 04000
00241 00000000 0000 HLT 07700
00243 00000000 0000 HLT 03000
00244 00000000 0000 HLT 03000
00245 00000000 0000 HLT 00000
00246 00000000 0000 HLT 00000
00247 00000000 0000 HLT 00000
00247 00000000 0000 HLT 00000
00247 00000000 0000 HLT 00000
00250 000000000 0000 HLT 00000
                                                                  05256 50472147 OPAR
                                                                                                                                                                                                        05336 00100365 083V BRH 00365
                                                                                                                                     05273 03356151 3./R PIN*16151 05274 02105275 28.. 05275 50256322 QETB E9M*16322.PP
                                                                                                                                                                                                       05334 00100365 0839 BR 00365
05337 04107606 48*6 BRX 07606
05340 00107660 08* BRU 07660
05341 03510330 3R3H STA 10330
                                                                   65257 25516060 ER
                                                                                                         ADD 16060.X
                                                                  05260 40006713 -0x= HLT 06713
05261 50632147 QTAP
                                                                                                                                     05275 43606060 L STB 06060
05277 40006452 -0U- HLT 06452
05300 50246444 QDUM E9M+06444,PP
                                                                                                         SUC 06060.X
                                                                   n5262 25606060 F
                                                                                                                                                                                                       05342 01411171 1J97 ETR 11171
                                                                  C5263 40006734 -OX1 HLT C6734
C5264 50236660 QCW EBM 36660,PP
                                                                                                                                     05300 50246444 QDUM E9M*06444,PP
05301 47660660 P LAD 60606
05302 40007637 *0.* HLT 07637
05303 50224646 QB89 E9M 246*6,PP
05304 63660600 T SB 06060,X
05305 40007736 *0.* HLT 07736
05305 50627043 QSYL
05307 24516060 DR
05310 40005410 *0.* HLT 05410
                                                                  r5265 60606060
c5266 40007237 -C.. HLT c7237
                                                                                                                                                                                                        05268 40007237 -01. HLT 07237
05267 50625123 GSRC
05270 30606060 H
05271 40007075 -0Y. HLT 07075
05272 50446227 GMSB
                                                                                                                                                                                                        * RECORD LENGTH: 00040 WORDS ***
00250 00000004 0004 HET 00004
00251 00000000 0000 HET 00000
00252 77770000 **00 E4X*30000;F
00253 00007777 00** HET 07777
                                                                  05273 60606060
05274 40007766 +0.W HLT 07766
                                                                                                                                                                                                        05323 03350077 3.0. PIN*10077 05324 02105325 28$E
                                                                  05275 11111111 9999
05276 00000000 0000 HLT 00000
05277 04377767 4..x BRM*37767
05300 00410325 0J3E
                                                                                                                                     05311 50472562 QPES
05312 66606060 W RSH 06060.X
05313 40007777 -0.. HLT 07777
                                                                                                                                                                                                        05325 50627044 QSYM
05325 50627044 QSYM
05326 31606060 I MRG 060604
05327 40007770 +0+Y HLT 07770
00254 00000000 0000 HLT 00000
DITTH THRU LBC 00257
                                                                                                                                                                                                                                               MRG 06060,PX
                                                                                                                                     05314 50627062 QSYS
                                                                                                                                                                                                        05330 50627062 QSYS
05331 63666660 T STR 06060.X
05332 40007771 -0.2 HLT 07771
05333 50223145 GBIN EAM 23145.PP
                                                                                                                                     05411 04377767 4 . . X BRM+37767
                                                                                                                                                                                                        05425 07306354 7HT* SKG 06354
                                                                  * RECORD NUMBER *005**************
* RECORD LENGTH: 00040 WORDS ***
                                                                                                                                     05412 00210325 0A3E E9M 10325
05413 07610325 7/3E LDA 10325
                                                                                                                                                                                                        05426 00105422 08*8 BRU 05422
05427 07606445 7 UN LDA 06445
05334 46606060 9 RSH 06060
05335 40007772 #0: HLT 07772
                                                                                                                                     05414 07211170 7A9Y SKA 11170
05415 00107675 08. BRU 07675
                                                                                                                                                                                                        05430 07506464 70UU LDA 06464
                                                                                                                                                                                                        05431 03606442 3
                                                                                                                                                                                                                                         UK STR 06442
                                                                                                                                                                                                        05432 01606447 1 UP MRG 06447
05433 07306352 7HT SKG 06352
05334 50627044 GSYM
05337 46666660 9 RSH 06060
05340 4003773 -0.. HLI 07773
05341 50223145 GBIN EM 23145.PP
                                                                                                                                     05416 00100365 083V BRU 00365
05417 04107606 48.6 BRX 07606
05420 00107660 08. BRU 07660
05421 03510330 3R3H STA 10330
                                                                   05353 03353207 3. 7 PIN*13207
                                                                                                                                                                                                        05434 00105455 08** BRU 05455
05435 13377777 **** PIN*37777
                                                                  05354 02105355 28$.
05355 50430222 QL2R
                                                                                                                                                                                                        05435 13377777 **** PIN*37777*PP
05436 00000000 0000 HLT 00000
05342 31606060 I
05343 40007774 +0.0
05344 50627062 05YS
05345 47606060 P
                                        17G 06060,Px 05356 60606060
                                                                                                                                     05422 01411171 1J97 FTR 11171
                                                                                                                                                                                                        05437 04377767 4..X BRM*37767
05440 00410325 0J3E
                              -0 - ( HLT 0/774
                                                                   05357 40007754
                                                                                                  .O.* HLT 07754
                                                                   05360 50430322 QL38
05361 60606060
05345 47606060 P LDA 06060
05346 40007775 -0.. HLT 07775
05347 50430022 QL08
05350 60606060
                                                                                                                                                                                                       05441 04377767 4..X BRM+37767
05442 00210325 0A3E E8M 10325
                                                                   05362 40007755 -0.. HLT 07755
                                                                                                                                     05443 07610325 7/3E LDA 10325
05444 07211170 7A9Y SKA 11170
05350 60606060
05351 40007752 -0.0
05352 50430122 GL18
                                                                   05364 60606060
                                                                                                                                                                                                        05444 0/2111/0 7A9Y SKA 111/0

05445 00107675 08** BRU 07675

05446 00100365 083Y BRU 00365

05447 04107606 48*6 BRX 07606

05450 00107660 08* BRU 07660

05451 03510330 3R3H STA 10330

05452 01411171 1J9Z ETR 11171
                                                                   05365 40007756 +0.1
05366 50430522 QL58
                              -0 .. HLT 07752
                                                                                                 -0., HLT 07756
                                                                                                                                     05403 03351576 3 •: • PIN*11576 05404 02105405 28*5 05405 50434722 QLPB 05406 6060600 05407 40007764 •0•U HLT 07764 05410 02000000 2000 Nep 00000
 05353 69696060
05354 40007753 -0.$ HLT 07753
                                                                  H03/0 40007757 +0.. HLT 07757
05371 50430622 QL68
05372 60606060
05373 40007745
                                                                   05367 60606060
05370 40007757
 05355 11111111 9999
05356 00000000 0000 HLT 00000
05357 04377767 4..x 38M*37767
                                                                   95373 40007760 +0. HLT 07760
05374 50430722 QL7R
05360 00410325 0J3E
05360 00410325 0J3E
05361 04377767 4..X 9RM-37767
05362 00210325 0A3E EAM 10325
05363 07610325 7/3E LDA 10325
05364 07211170 7A9Y SKA 11170
                                                                   05375 60606060
05376 40007761 •0./ HLT 07761
                                                                                                                                     05411 03506442 3QUK STA 06442
05412 03606421 3 U4 STB 06421
05413 04630003 4T03 RCH 30003
                                                                                                                                                                                                        555555555555555555555555555555555555
                                                                                                                                                                                                        55555555555555555555555555555555555
                                                                   05377 50235122 QCRR E8M 35122,PP
                                                                                                                                                                                                        05414 03506425 3GUE STA 06425
05415 07506452 7QU. LDB 06452
05415 07106405 78U5 LDX 06405
05417 25506457 CQU. STA 06457,
05420 04105417 48** BRX 05417
                                                                   05400 60606060
05365 00107675 08** 3qU 07675
05366 00100365 0839 BRU 00365
05367 04107606 48*6 BRX 07606
05370 00107660 08* BRU 07660
                                                                   05401 40007762 +0.5 HLT 07762
05402 50234722 QCPR EDM 34722,PP
                                                                                                                                                                                                        5555555555555555555555555555555555555
                                                                    05403 60606060
05404 40007763 =0.T HLT 07763
                                                                   05404
                                                                   05405 11111111 9999

05406 00000000 0000 HLT 00000

05407 04377767 4**X RRM*37767

05410 00410325 0J3E
                                                                                                                                     05421 03606452 3 U. STB 06452
05422 04305502 4H.2 BRM 05502
 0537
            03510330 3R3H STA 10330
 05372 01411171 1J9Z ETR 11171
                                                                                                                                     05423 04305641 4H; J BRM 05641
05424 07606441 7 UJ LDA 06441
```

Fig. 2 (contd)

```
12:13 MAY 29:173 ID=0010=F00
   J08 CCK, TEST-PDP11-DUMP
ASSIGN M⊯I, (FILE, PDP11), (IN)
  RUN (LMN, DUMP)
*W8RD=16
*RYTF = 8
  *ADDRESS=AYTE, BCT
 *CHAR = ASCIT
 *ROTATE:8
 *START*REC+2: NANANANANANNNANA-6
 *NEWLRC=KEC+2:NNNNNNNNNNNNNNNNNNNNNN-4

*INSDEF: 1112223334+4555

*PRTDFF:MMMM LLA LLA

*PARAM: 2+! IT= R, 2, +,2+, -,2-, X,8X

*PARAM: 4+! IT= R, 7, +,0+, -,3-, X,2X

*HEAD: AP SPC DST
 *8PS*8CT
*END
WARNING: THIS IS THE END
***CONSISTENCY TEST FOR TABLES***
  LOC LILLLE 44 SP SRC DST LOC LLELLE AA SP SRC DST
                                                                                                                                                                                                LOC LLLLL AA OP SEC DST
                                                                                                                                                                                                                                                                                               LOC LLLLL AA BP SRC DST
 * RECARD NUMBER *001******* * RECARD NUMBER *002********* * RECARD NUMBER *003****** * RECARD NUMBER *004************

* RECARD LENGTH: 00026 NORDS *** * RECARD LENGTH: 00026 WORDS *** * RECORD LENGTH: 00026 WORDS *** * RECORD LENGTH: 00026 WORDS *** * * RECORD LENGTH: 00026 WORDS *** * * * RECORD LENGTH: 00026 WORDS ** * * * RECORD LENGTH: 00026 WORDS *** * * * RECORD LENGTH: 00026 WORDS ** * * * * RECORD LENGTH: 00026 WORDS ** * * * REC
                                                                                                                                                                                              37126 000001 •• SPCL R0 R1
37130 000064 •4 SPCL R0 X4
37132 037134 > BIT 8x1 8+4
37134 006104 •D SPCL X1 R4
37136 006101 •A SPCL X1 R1
 36772 000001 . SPCL
                                                                                               37050 000001 .. SPCL
                                                                                                                                                              RO R1
                                                                                                                                                                                                                                                                                             37204 000001 .. SPCL RO R1
36774 000064 •4 SPCL R0
36776 037000 >• BIT #X0
37000 010415 •• MAV R4
37002 124040 ( CMPB -C
                                                                                              37052 000001 - SPEL
37052 000064 - SPEL
37054 037056 >- RIT
37056 110167 -- MBVB
37060 140504 AD BICB
                                                                                                                                                                                                                                                                                             37206 000001 ** SPCL RO 8**
37206 00005* * SPCL RO 8**
37210 037212 * BIT 8½ 82
37212 110103 * C M6V8 R1 R3
37214 005002 * SPCL 8** R2
                                                                                                                                                          RO X4
0X0 0=6
                                                                          R0
85
                                                                                                                                                              R1
R5
                                                                                                                                                                         χ7
                                                                                                                                                                                             37136 006101 *A SPCL X1
37140 006104 *D SPCL X1
37142 006101 *A SPCL X1
37144 105702 *B SPLB a-7
37156 105302 *B SPLB a-3
37152 001336 * SPCL a3
37154 005702 *B SPCL a3
37154 005702 *B SPCL a-7
37156 105702 *B SPCL a-7
37156 105704 *L SPCR R7
                                                                                               37062 012700 • a May
37064 037242 > RIT
37066 120120 F CMPB
 37004 111001
                                     . Mevs
                                                                          ρ1
                                                                                                                                                                                                                                                                                             37216 011504 +D MBV a5
37220 105002 ++ SPLB a+0
                                                                                                                                                              0X2 =2
R1 +0
00 R5
X0 +7
R0 R6
 37006 000420
                                     . SPCL
                                                                                                                                                           ax2
                                                                                                                                                                                                                                                          x1
อ≖7
                                                                           +0
                                                                                                                                                                                                                                                                                                                                                                         R2
                                                                                              37066 120120 P CMPB
37070 001005 •• SPCL
37072 116027 •• MBVB
37074 000006 •• SPCL
 37010 010504
37012 110301
                                     VEM 3+
                                                               рK
                                                                                                                                                                                                                                                                                              37222 152702 UB BISB
                                                                                                                                                                                                                                                                                             37224 000006 • SPCL RO
37226 012701 • A MBV +7
                                                               R3
                                                                                                                                                                                                                                                             ้อ7 อ+1
 37014 000415
                                     .. SPCL
                                                                           a5
                                                                                                                                                                                                                                                                      R2
 37016 010405
                                                               R4
                                                                                                                                                                                                                                                                                              37230 000060
                                                                                                                                                                                                                                                             a3 a+6
                                                                                                                                                                                                                                                                                                                                  .O SPCL
                                                                                                                                                                                                                                                                                                                                                             RO
                                                                                                                                                                                                                                                                                                                                                                         ΧO
                                                                                              37074 000006 • SPCL 37076 037000 > RIT 37100 000177 • SPCL 37102 177772 • 37104 002700 % CMP 37106 037252 > RIT 37110 001366 • SPCL 37112 006001 • SPCL 37112 006001 • SPCL 37114 006001
37020 006205 .. SPCL X2
37022 006305 .E SPCL X3
37024 110103 .C M6V3 R1
37026 005004 .. SPCL 3-0
                                                                                                                                                                                              37154 005702 •B SPCI
37156 100714 •L SPLE
37160 012701 •A M8V
37162 000015 •• SPCI
                                                              X2
X3
R1
                                                                                                                                                           8X0
R1
8X7
                                                                                                                                                                                                                                                                                              37232 006304 .D SPCL
                                                                                                                                                                                                               10071# .L SPLB
                                                                                                                                                                                                                                                                                              37234 103001 .. SPLB
                                                                          ВЗ
                                                                                                                                                                      8 X 2
                                                                                                                                                                                                                                                                                             37236 005201 ..
37240 000703 .C
                                                                                                                                                                                                                                                                                                                                           SPCL 8-2
SPCL R7
                                                                                                                                                                                              37162 000015 •• SPCL
37164 000731 •• SPCL
37166 005767 •• SPCL
37170 140376 a• BICB
                                                                                                                                                                                                                                                            R0 a5
R7 a+1
                                                                           62
                                                                                                                                                                                                                                                                                              37242 056377
 37030 005002
                                     •• SPCL %=0
•0 MAV +7
                                                                                                                                                           ax2 a +2
                                                                                                                                                                                                                                                                                                                                     . BIS
                                                                                                                                                                                                                                                                                                                                                             x3 ax7
 37032 012700 .0 MeV
37034 177560 ..
                                                                                                                                                                                                                                                                                             37244 005015 · · 37246 136615 . ·
                                                                                                                                                                                                                                                                                                                                            SPCL 8-0
                                                             9X5
                                                                                                                                                                                                                                                             R3 8X6
                                                                          ХC
                                                                                                                                                              ΧO
                                                                                                                                                                                                                                                                                                                                          BITB
                                                                                                                                                                                                                                                                                                                                                                       a5
                                                                                               37114 006001 •• SPCL
37114 006001 •• SPCL
37116 006001 •• SPCL
37120 142701 EA BICB
37122 000377 •• SPCL
 37036 005210 .. SPCL
37040 105710 .H SPLB
                                                            a-2
a-7
                                                                                                                                                                                               37172 001715 +M
37174 005725 +U
                                                                                                                                                                                                                                                                                                                                          SPCL
                                                                                                                                                                                                                                           SPCL
                                                                                                                                                                                                                                                                        ล5
+5
                                                                                                                                                                                                                                                                                              37250 002240
                                                                                                                                                                                                                                                                                              37252 002004 ..
                                                                           20
                                                                                                                                                               X0
+7
                                                                                                                                                                                                                                                                                                                                                             40
 37040 103710 • F SPLB 177
37042 100376 • • SPLB R3
37044 005720 • F SPCL 2-7
37046 111001 • • M8VB 20
37050 105767 • • SPLB 2-7
                                                               R3 พิxั6
                                                                                                                                                                         R1
                                                                                                                                                                                               37176 005102 .B SPCL
                                                                                                                                                                                                                                                                                              37256 102016 .. SPLB
                                                                                                                                                                                                                                                                         R4
R6
R5
                                                                           +0
                                                                                                                                                              R3 ax7
                                                                                                                                                                                               37200 01050# +D M8V
                                                                                                                                                                                                                                                             R5
R4
                                                                                                                                                                                                                                                                                                                                                             40
37046 111001
37050 105767
                                                                          R1
                                                                                               37124 152701 UA BISB
                                                                                                                                                                                               37202 000406
                                                                                                                                                                                                                                    .. SPCL
                                                                                               37126 000006 •• SPCL
37130 006104 •D SPCL
                                                                                                                                                               RΩ
                                                                                                                                                                                               37204 010405
                                                                                                                                                                                                                                                                                             86
                                                                                                                                                                                                                                    ..
                                                                                                                                                                                                                                            MâV
                                                                                                                                                                                                                                                              R4
 37052 140510 AH RICH
                                                               DE
                                                                                                                                                                                              37206 006205 .. SPCL
37210 006305 .E SPCL
                                                              R3 9.X5
 37054 100375 .. SPLB
                                                                                               37132 006101 .A SPCI
                                                                                                                                                                                                                                                                                             77773 000001 .. SPCL
                                                                                                                                                                                                                                                                                             77775 000006 .. SPCL RO R6
77777 000001 .. SPCL RO R1
                                                                                                                                                                                                                                                                                              *********
```

Fig. 3. An application of the Universal Dump Program to the PDP-11 computer

THE 930 INSTRUCTION:





Fig. 4. Instruction format for the XDS 930 computer

THE PDP-11 INSTRUCTION:



BIT	FUNCTION
0-3	OPERATION CODE
4-6	ADDRESSING MODE FOR SOURCE OPERAND
7-9	SOURCE OPERAND REGISTER
10-12	ADDRESSING MODE FOR DESTINATION OPERAND
13-15	DESTINATION OPERAND REGISTER

Fig. 5. Instruction format for the PDP-11 computer